
D1200 Door Closer RYOBI STANDARD INSTALLATION


19 **RYOBI Limited** EN1154:1996/A1:2002/AC:2006 D-1200

Door closer	strength selection
Strength specification	Usable door weight(kg)
Power EN3	40~60
Power EN4	60~80


and screw sel	ection
Metal door	Wooden door
Ø4.2	Ø3.8
M5	ST4.8
	Metal door Ø4.2

- 1.Install the door closer according to the specification of installation diagram; Meanwhile make sure that all the screws are fastened.
- 2. The valves are prohibited to screw out of the door closer, while adjusting the closing and latching speed;
- 3. When closing the door ,no additional forces by hand, if not maybe the door closer will be failure.
- 4.If do not follow this installation, the company is not responsible for the consequences caused.
- 5.Max opening angle is 180°.





TOP JAMB INSTALLATION Closer mounted on top jamb on push side of door.



D1200 Door Closer RYOBI STANDARD INSTALLATION

19 **RYOBI Limited** D-1200


Door closer strength selection		
Strength specification	Usable door weight(kg)	
Power EN3	40~60	
Power EN4	60~80	


Door closer	strength selection
Strength specification	Usable door weight(kg)
Power EN3	40~60
Power EN4	60~80


Door closer strength selection	
Strength specification Usable door weight(k	
Power EN3	40~60
Power EN4	60~80


Drill and screw selection		
Door types	Metal door	Wooden door
Drill	Ø4.2	Ø3.8
	M5	ST4.8
screw		


- 1.Install the door closer according to the specification of installation diagram; Meanwhile make sure that all the screws are fastened.
- 2. The valves are prohibited to screw out of the door closer, while adjusting the closing and latching speed;
- 3. When closing the door ,no additional forces by hand, if not maybe the door closer will be failure.
- 4. If do not follow this installation, the company is not responsible for the consequences caused.
- 5:Max opening angle is 180°.












RYOBI

D-1200 Door Closer Parallel arm Installation

- 1.Install the door closer according to the specification of installation diagram; Meanwhile make sure that all the screws are fastened.
- 2. The valves are prohibited to screw out of the door closer, while adjusting the closing and latching speed;
- 3. When closing the door ,no additional forces by hand, if not maybe the door closer will be failure.
- 4.If do not follow this installation, the company is not responsible for the consequences caused.
- 5.Max opening angle is 180°.

Drill and screw selection		
Door types	Metal door	Wooden door
Drill	Ø4.2	Ø3.8
	M5	ST4.8
screw		





- 1.Install the door closer according to the specification of installation diagram; Meanwhile make sure that all the screws are fastened.
- 2. The valves are prohibited to screw out of the door closer, while adjusting the closing and latching speed;
- 3. When closing the door ,no additional forces by hand, if not maybe the door closer will be failure.
- 4.If do not follow this installation, the company is not responsible for the consequences caused.
- 5.Max opening angle is 180°.

Drill and screw selection		
Door types	Metal door Wooden door	
Drill	Ø4.2	Ø3.8
	M5	ST4.8
screw		

