



WE.LOCK

Minimal
in world
Smart lock
WE.LOCK



Setting

Smart lock open the door, Only change lock Cylinder

APP download



WE.LOCK

Method 1: Scan "WE.LOCK" QR code then install it.

Method 2:

- 1) IOS system users find "WE.LOCK" in the APP store then install it.
- 2) Android system users find "WE.LOCK" in the Google play market.

APP use the steps

A. Register



B. Scan the QD code or input the No. of the QD code and connect the bluetooth lock



C Connecting the Bluetooth lock (In order to save electricity, Bluetooth will be disconnected from lock automatically after unlock)



Instructions for installing the video

As The Picture Shows :



More details



1 Fix the screw hole

2 After the handle

3 Fixed cylinder screw hole

4 Lock core pull tablets

5 Length adjustment node

6 Battery compartment

7 Adjust the screws

8 Housing fixing screws

9 Set key

10 Return key

11 Stainless steel shell

Remove handle / lock length adjustment

With the supplied hexagonal screwdriver, loosen the fixing screw

Pull the handle backwards to remove / adjust the length of the lock cylinder

